操作指南

INSTRUCTIONS

01 产品清单

1. 主机一台
2. 适配器一个
3. 说明书一份

02 功能说明

1. 红外感应
2. 10秒时间设定
3. 30秒时间设定
4. 60秒时间设定
5. LED显示屏
6. 99秒时间设定
7. 适配器插口



03 产品信息

1. 产品名称: LG203美甲光疗灯
2. 型号: LG1-23
3. 功率: 72W
4. 灯珠: 36pcs
5. 波长: 365+405nm
6. 输入电压: 100-240V 50/60Hz
7. 尺寸: 290x234x110mm

【机器教学视频二维码】

04 操作流程

1. 将电源适配器插入电源插座;
2. 点击时间按键,机器启动后,可通过时间设定按键进行10s/30s/60s/99s的时间设定,按下对应按键时LED屏会显示对应时间。
3. 不使用时间设定按键,手放进机器,红外感应将会启动机器最大工作时长120s,前50s为无痛模式。



05 注意事项

01. 为保证本产品的耐用性与可靠性,请按照说明内容操作。本公司不承担因未仔细阅读使用说明书及不规范操作而造成事故的责任。
02. 请使用与本产品相匹配的配件。
03. 请使用正确的电源电压。充电器应连接接地线,以防当产品出现故障或者漏电时,有触电的危险。
04. 不可使用已经破损的电源插座,可能导致触电和引起火灾等危险。
05. 请勿让水或其他类型的液体进入机器,以避免引起机器故障。
06. 本产品周围不可放置热源,避免靠近蜡烛、烟头等火种,可能会引发火灾。
07. 如果长时间不使用机器,请从插座上拔出适配器。
08. 眼睛不宜直视灯光及长时间照射。
09. 请勿私自拆开产品,否则有可能造成损坏现象。
10. 请将本产品放置在儿童不可触及的位置。

06 售后要求

1. 请勿私自拆开产品,务必要技术专业的操作人员来维修装卸,否则有可能造成损坏。如果您已经拆卸,又不知如何复原,请与售后服务人员联系。
2. 生产日期不可撕坏,撕毁无效。
3. 电源线只能适用于原装配件,不可以擅自使用其他的配件!其他适配器导致机器故障,一律不负责。
4. 遇到个人无法解决的问题时,请将产品型号和故障情况告知售后服务人员,我们会为您提供解决办法。

产品保修:

1. 主机保修一年,电源线不保修。(6个月之内有问题,运费可报销,境外地区及偏远地区除外)
2. 不保修范围:
   - ⊙ 因用户未按照说明书指导使用而造成的故障。
   - ⊙ 使用不匹配电压所造成的损坏。
   - ⊙ 不可抗力事件,如:火灾、洪水、地震等所造成的损坏。
   - ⊙ 用户使用不当或擅自拆卸所造成的损坏。
   - ⊙ 使用非原装配件做造成的损坏。
   - ⊙ 安装或搬运过程中摔落所造成的损坏。
3. 如若人为损坏,本公司提供有偿售后服务!维修中涉及更换零件的,收取零配件费用。维修过程中所产生的运费应由使用者自行承担。

产品型号:_____

经 销 商:_____ 采购日期:_____年____月____日

用户姓名:_____ 联系电话:_____

用户地址:_____

故障原因:_____

_____

洛爵丝官方售后联系方式: 13229472642 / 微信同号

收货联系人: 欧莉源美甲厂(售后) 13922351579

收货地址: 广东省佛山市南海区里水镇文安路文头岭西侧旧石场2楼(欧莉源美甲厂)

CE FC

INSTRUCTIONS

01 PRODUCT LIST

1. Machine main body
2. Power adapter
3. Manual

02 FUNCTION DESCRIPTION

1. Infrared induction
2. 10s time setting
3. 30s time setting
4. 60s time setting
5. LED display screen
6. 99s time setting
7. Adapter interface



03 PRODUCT INFORMATION

1. **Product name**: LG203 UV/LED nail lamp
2. **Model**: LG1-23
3. **Power**: 72W
4. **Lamp beads** : 36pcs
5. **Wave length**: 365+405nm
6. **Input Voltage**: 100-240V 50/60Hz
7. **Size**: 290x234x110mm

【QR Code of the instruction】

04 OPERATION PROCEDURE

1. Plug the power adapter into the power socket;
2. Click the time button,after the machine starts, the time setting button can be used to set the time for 10s/30s/60s/99s,when the corresponding key is pressed the LED screen will display the corresponding time.
3. If not use the time setting button, and put your hand into the machine, then the infrared induction will be start the machine maximum working time of 120s ,the first 50s is in low heat mode.



05 ATTENTION ITEM

01. Please follow the instructions to ensure the product's durability and reliability. Our company will not responsible for accidents caused by failure to read the instructions carefully and irregular operations.
02. Please use accessories that match this product.
03. Please use the correct power supply voltage. The charger should be connected to the ground to prevent the risk of electric shock once the product fails or leaks.
04. Do not use damaged power sockets, it may cause electric shock and fire.
05. Please not let the water or any other liquid into the machine, lest cause breakdown.
06. Do not place a heat source around this product, keep away from burning candles, cigarette, etc., which may cause fire.
07. Please not connect the power socket when you not use the machine at a long time.
08. Please not stare the light straightly and explosure for a long time.
09. It may cause damage if the machine is disassembled without instruction.
10. Keep this product out of children's reach.

06 AFTER-SALES SERVICE

1. Do not disassemble the product privately, it requires professional staff to repair, otherwise it may cause damage. Please contact the after-sales service if you have disassembled it and do not know how to recovery.
2. Do not tear the production date label, or it's invalid.
3. The power cord can only be used on the original accessories, can not used with other accessories. Exclusive adapter with special designed label, we'll not take responsibility if problems caused by other adapters.
4. Please inform the after-sales service about the product's model and its problem when you meet problems cannot be solved by yourself. We will offer you solutions.

Warranty

1. One year guaranteed for the main unit of the machine, no guaranteed for the power cord.
2. No warranty coverage:
   - ⊙ Problems caused by the user do not following the manual instructions.
   - ⊙ Damage caused by unmatched voltage.
   - ⊙ Damage caused by improper use or destruction by the user.
   - ⊙ Damage caused by using non-original accessories.
   - ⊙ Damage caused by falling during installation or transportation.
   - ⊙ Force majeure events, such as damage caused by fire, flood, earthquake, etc.
3. The free repair is unavailable if the damage is caused by person. The repair fees will be charged according to the maintenance parts. Shipping fees will also be charged.

Product model:_____ Purchase date:____D___M___Y

Distributor:_____

Customer name:_____

TEL.:_____

Address:_____

Fault cause:_____

_____

L'UGX® official after-sales service contact way:
+86 13229472642 / WeChat contact same number

CE FC